

ELECTRIC SCOOTER

Instruction Manual

Model : Q30—series



ARWIBON

Please read the manual carefully before using this product

Table of Contents

Title	Page
Packing List -----	1
Product Parameters -----	2
Assembly Instructions -----	3-4
Product Part Name -----	5
Schematic Diagram Of Meter Icon -----	6
Regular Inspection&Maintenance -----	7
How To Use The Charger Corectily -----	8
Safety Instructions -----	9
After Sales -----	9

Packing List

Dear Customer :

Thank you for choosing our electric scooter. After opening the package, please carefully check whether the accessories you received are complete. If there are any discrepancies, please contact us in time, and we will reissue it to you as soon as possible.



● Q30 -OFF-ROAD ELECTRIC VEHICLE



● ACCESSORIES
BRAKE PADS
EXTENDED FENDERS



● SCOOTER LOCK



● ASSEMBLY TOOLS



● CHARGER



● INSTRUCTION
MANUAL

Product Parameters

Product Name	Q30 Electric Scooter
Charging Port	Double
Brake method	Disc Brake
Shock Absorption	Enhanced Shock Absorption
Tire	11"Off-road Tubeless Tire
Mudguard	Lengthened Lifiable Mudguard
Acceleration Button	Three Gears
Throttle	Finger Pressure
Anti-theft Settings	Key Lock
Back handle	Available
Weight	33kg
Package Size	1273*273*515mm



ARW/BON

Assembly Instructions

At the same time, we have a free mudguard extension piece as a gift to help you better block water splashes on rainy days.



plastic rear fender



Before



After

In order to facilitate packing, we lowered the fender, you can loosen the screw at this position and raise the fender to achieve the best results.



Loosen screw adjustment



Before




After

Assembly Instructions



1. remove all packaging materials of scooter after unpacking



2. Put the car away and press the fold switch



3. Pull the lever hard



handlebar mounted



Tighten the screws



Handlebars aligned with front wheel



1. Adjust the handlebars to the position that suits you




5. The handlebars can be stretched into place




6. Assembly is complete

Product Part Name



Schematic Diagram Of Meter Icon



INSTRUMENT COMMONLY USED ICONS


		ECU					
CHARGE	MOTOR FAILURE	CONTROLLER FAILURE	BRAKING	1ST GEAR LOW SPEED	2ND GEAR MEDIUM SPEED	3RD GEAR HIGH SPEED	HANDLEBAR FAILURE
		TRIP	ODO				
HANDLEBAR FAILURE	THE WIDTH LIGHT	SINGLE MILEAGE	TOTAL MILEAGE	TURN LEFT	TURN RIGHT	R GEAR REVERSE	P GEAR PARK

Regular Inspection & Maintenance

NO.	Parts	How to do?
1	Shock absorber	Every 1-2 months, you can add lubricating oil to the shock absorber to reduce wear and tear.
2	Fold switch	Every 1-2 months, you can add lubricating oil to the Fold switch to reduce wear and tear.
3	Battery	When the scooter will not be used for a long time, please fully charge it every one month.
4	Brake Pads	The brake pads can be replaced with new ones after one year of use to achieve better braking results.
5	Tires	This scooter has vacuum tires, you feel the tires flat, you can inflate it.
6	Screws	After using the scooter for half a year, check whether the screws of the whole body are loose.

How to use the charger corectly

1. When charging with the charger, the charging port of the scooter should be connected first (Please align the the output port of the charger with the scooter's charging port).
2. The charging place should be far away from children, and ensure that the charging environment is ventilated, dry, and away from flammable and explosive materials.
3. Please be sure to use the company's special charger for charging. otherwise it will affect the life of the battery or damage the battery.
4. After the charger turns green, unplug it within two hours to stop charging.
5. It is forbidden to connect the charger to the power supply without load.
6. After the charging is completed, you should first pull out the power plug before pull out the plug of the scooter.
7. After the power is turned on, the red light indicates that the charging is in progress. When the charger indicator turns to green, the charging is completed. When the battery is almost full, the red and green lights will flash alternately.
8. This scooter has 2 charging ports, the other one can be used as a backup charging port. You can also charge 2 charging ports at the same time, and unplug it in time after it is fully charged.



ARW/BON

Safety Instructions

1. This product is limited to one person do not carry other people at the same time.
2. It's better to wear safety helmets and other protective equipment when riding this product, pay attention to riding safety.
3. Please practice in the flat and wide outdoor place with low traffic flow first and then drive on the road after you are proficient in driving it.
4. Never ride this product in an unsafe or illegal place and use it in accordance with local traffic laws.
5. Do not turn off the power while riding the scooter.
6. Do not try to directly pass the steps with a gap of more than 5 cm. it may cause the scooter to overturn causing human injury or damage to the scooter, try to avoid them and ride on flat road.
7. Do not use this product in an environment below -5°C.
8. Keep your feet on the scooter as far as possible while driving it (and the support stand is retracted), pay attention to balancing your body's gravity.
9. When passing rough roads, please slow down and drive carefully.
10. Never ride the scooter on oily or icy surfaces, be careful not to slip, safety first.
11. The user must adjust the height of the product to an appropriate position, and all parts (brake frame, handlebars, wheels, saddles) that need to be locked must be locked. check it before riding, otherwise it will cause injury or damage.
12. This product is a waterproof device but not completely waterproof. Do not immerse the product in deep water or be directly sprayed with water as it may cause motor and circuit failures.