



picture47



picture48





































## 8 > Charging

Charging time, battery charging at the end of the hole <as shown in figure 47, shown in figure 48 >.



# Assembly Manual Model UB9049E

# PACKING LIST

							
Rear frame: 1set	Front frame: 1set	Wooden plate:1 set	Front wheel set: 2 wheels Front fenders: 2 pcs	Box Cover: 1 set Rain Cover : 1set	Canopy tube:2 pcs	Angle iron (2pcs long 2pcs short): 4 pcs	
							
Display:1 pc	Saddle:1 pc	Charger: 1 pc	Safety belt:4 pcs	Pedal:1pair	Seat post:1 pc	Front light : 2 pcs Screw: M5*12, round cross:2 pcs	Bell:1 pc
							
Front reflector: 2pcs	Disc: 2 pcs Screw:M5, 12 pcs	Hydraulic: 1 set Washer:Ø6, 12pcs Screw:M6, 4pcs	Clay plate: 4pcs Screw: M5*12, round cross 8 pcs Washer:Ø5 8 pcs Nylon nut: M5, 8 pcs	Damper: 1pc Washer:Ø10, 2pcs Nylon nut:M10, 2pcs	Steering column parts: 1pc Spring shim:Ø18, 1pc Nut:M18, 1pc	Connect parts:1pc Screw:M8*40, 1pc Nylon nut:M8, 1pc	Bearing:7204, 1pc 329/32, 1pc
							
Handlebar bushing: 2 pcs Bushing of Canopy tube:4 pcs	Screw: M6*30,Cross flat head screws:4 pcs Nylon nut: M6, 4 pcs Plastic guide roller : Ø6, 4 pcs	Seat plate: 2pcs Screw:M6*20, 2pcs M6*25, 2pcs Nylon nut:M6,4pcs	Seat lock: 1pc Seat lock parts: 1pc Screw:M4*20, 4pcs Nylon nut:M4, 4pcs	Screw:M6*25, 18pcs Washer:Ø6, 18pcs Cap nut:M6, 18pcs	Screw:M6*25, 2pcs Washer:Ø6, 2pcs Cap nut: M6, 2 pcs	Screw: M6*30 ,Cross flat head screws : 8 pcs Cap nut: M6, 8 pcs	Screw: M6*70,Round cross, 2 pcs Washer:Ø6, 2 pcs Nylon nut: M6, 2 pcs
							
Screw:M6*20, 8pcs Washer:Ø6,8pcs Nylon nut:M6,8pcs	Ribbon: 3 pcs Protector cover: 2 pcs	Screw:M5*25, 1pcs Washer:Ø5,2pcs	Article shockproof: 2 pcs	Disc brake screw : 1set			



picture1



picture2




picture3



picture4



picture5



picture6



picture7

## 1 > Assemble front wheel & fender


Let the front fender in a bottom frame on both sides respectively, with clay plate on the front end small tubes, after adjust the fender then screw locking < as shown in figure 1-4 >;

The fasteners used for M5X12 round head cross, flat pad attached & nylon nuts <as shown in figure 3>;

Disc will be loaded on the front wheel <as shown in figure 5 >;

The front wheels are available on either side of the bottom box hooked claws on, straighten before locking <as shown in figure 1, figure 7 >.


(\*Note: don't put wrong direction of tire)



picture8



picture9



picture10



picture11



picture12



picture13

## 2 > Assemble front bottom & rear frame

Get the bearing <as shown in figure 8 >, the bearing shell type bottom box center hole of the upper and lower end <as shown in figure 9 >;

Will turn to the first column from down to up into the frame head tube, combined the bearing 329/32 on<as shown in figure 10 to 12 >;

Connection front bottom frame and rear frame, steering column parts from the bottom upwards through the bottom frame to center hole on the bearing 7204;



picture14



picture15



picture16



picture17



picture18



picture19



picture20



picture21

Will connect piece put into the steering column parts, twist the steering column parts spring washers and nut, on the other end of the connect parts in the small square tube frame and alignment hole, insert screw, screw nut, locking screw <as shown in figure 14 to 19 >;

Mount damping rod <as shown in figure 20, 21 >.

(\*Note:pay attention to the right direction )



picture22



picture23



picture24



picture25

Fix the left and right front light on the fender around as shown in Figure 22 and 23.

Fix the hydraulic disc pump with M5\*25 internal hexagon and Φ5 washer on the bottom frame as shown in Figure 24 and 25



picture26




picture27



### 3 > Assemble box angle iron

Angle respectively is assembled on the bottom frame four angles <as shown in figure 26-27>, fasteners used for M6X30 big flat head cross, attached to the cap nut.

(\*Note:that the installation position and direction of angle iron don't misplace)



picture28





picture29

### 4 > Assemble wooden box

Fix the lock with M4\*20 flat head cross and M4 nylon nut on the seat plate baffle; Fix the lock hook with M4\*20 flat head Cross and M4 nylon nuts on the seat plate as shown in Figure 28

Fix the seat belt with M6\*20 large flat head cross, M6 nylon nut, Φ6 flat washer on the seat plate and rear plate as shown in Figure 29



picture30



picture31



picture32






Seat plate assemble on box front side, fixed on the side panel on both sides, box front seat plate put article shockproof both front side <as shown in figure 30,31>;


The handlebar tube and canopy tube top pipe casing pipe respectively set into the plastic bushing <as shown in figure 32 >.



picture33



picture34



picture35

## 5 > Assemble belt & reflectors & plastic guide roller & front lights

Will seat belts respectively fixed on the box seat front and rear, with M6X20 big flat head


cross & nylon nut lock <as shown in figure 33>;

Assembly plastic roller <as shown in figure 34,35 >;

Front reflectors and lights assembly <as shown in figure35>;




picture36



picture37



picture38



picture39



claw of the lateral and pads on each screw three gasket


## 6 > Assemble handlebar & disc brake

Assemble the display, bell and brake lever on the handlebar as shown in Figure 36


Fix the brake oil tube to the bottom frame with cable ties as shown in Figure 37

Use a cable tie to tie the hanging wire as shown in Figure 38

Fix the disc brake to the bottom frame with disc brake screws (note add 3 washers on each screw) as shown in Figure 39



picture40



picture41



picture42

## 7 > Assemble the brake cable

Assemble the brake cable with plastic cable pipe shown in Figure 40

Fix the brake cable with M6\*20 flat cross head show in Figure 41 , and finished as 42



picture43



picture44



picture45



picture46

## 7 > Assemble canopy & box cover

Canopy tube inserted into the bushing, set on canopy, buckle fastening belt, the rubber band on the roller < as shown in figure 43, 44 >;

Remove the box cover, set in the cargo bike , buckle fastening belt, the rubber band on the roller < as shown in figure 45, 46 >.

(\*Note: the gap on the rear side)